

- 1/ draw holes position on top
- 2/ draw holes position on other parts, drill (use a jig for perfect work) and glue slots
- 3/ drill top board with 10mm depth (wrap tape on the bit as marker), put all wood dowels, glue edge panels and holes
- 4/ use clamps for tightening
- 5/ it's done ! Don't forget to place the license on it. Use the logo as stencil and spray for example.

