


## ARCHIPEL ARMCHAIR

### Materials


- plywood panel 18 mm or 3 layer wood panel 19 mm
- wood screws  $\approx \varnothing 3.5 \times 40 \text{ mm}$


### Tools

- hand saw, circular saw, jigsaw
- drill, drill bit 3mm, screwdriver...
- sander, paper sand...





one frame, two models













## ARCHIPEL ARMCHAIR







## ARCHIPEL ARMCHAIR






## ARCHIPEL ARMCHAIR







## ARCHIPEL ARMCHAIR

## Upholstery (without sewing)

- fabric cover
- cotton or polyester batting
- high resiliency latex or PU foam Blocks
- sandow
- eyelets
- safety pin

